

Article number changes **Linear unit connectors**

Old Nr.	New Nr.	Order key old	Order key new
KNK	KK.E	KNK 1818 11 1100-VO	KK.E-B18-B18-1-1
KNKE	KK.E	KNKE 1818 2M 2200-VG	KK.E-G18-B18-2-ED
KNK	KK.Z	KNK 1818 12 2200-VOZ	KK.Z-B18-B18-2-2
KNKE	KK.Z	KNKE 1818 2M2200-VGZ	KK.Z-G18-G18-2-ED
KNS	KS.E	KNS 3030 12 2200-VO	KS.E-B30-B30-40-2-2
KNZ	KS.E	KNZ 4040 18 2200-VG	KS.E-G40-B40-56-2-8
KNSE	KE.E	KNSE 3030 2M HH00-VG	KE.E-G30-B30-40-A-4
KNS	KS.Z	KNS 5050 12 1100-VOZ	KS.Z-B50-B50-65-1-2
KNZ	KS.Z	KNZ 4040 18 22-VGZ	KS.Z-G40-G40-2-8
KNSE	KS.Z	KNSE 3030 2M HH00-D-VGZ	KE.Z-G30-G30-B-4
KUS	KSU.E	KUS 3018 11 1100-VO	KSU.E-B30-B18-1-1
KUS	KSU.Z	KUS 5030 18 2200-VOZ	KSU.Z-B50-B30-2-8
KNR / KNRZ	KM.E	KNR 3030 12 11110-VO	KM.E-B30-B30-50-1-2
KNV / KNVZ	KM.E	KNVZ 4040 18 2222-VO	KM.E-B40-B40-60-2-8
KNU / KNUZ	KM.E	KNU 5050 11 1111-VO	KM.E-V50-B50-76-1-1
KUR	KMU.E	KUR 3050 18 2222-VO	KMU.E-B30-B50-2-8
KUV	KMU.E	KUV 4050 12 1111-VO	KMU.E-V40-V50-1-2
KNRV / KNRV	KMU.E	KURV 3040 12 2222-VO	KMU.E-B30-V40-2-2
KNR / KNRZ	KM.Z	KNR 3030 12 1111-VOZ	KM.Z-B30-B30-1-2
KNV / KNVZ	KM.Z	KNV 5050 18 2222-VOZ	KM.Z-V50-V50-2-8
KNU / KNUZ	KM.Z	KNUZ 3040 11 1111-VOZ	KM.Z-B30-V40-1-1
FLK	FK.E	FLK 1800 12 1000-VO	FK.E-B18-1-2
FLKE	FK.E	FLKE 1800 2M 2000-VG	FK.E-G18-2-ED
FLS	FS.E	FLS 3000 12 2000-VG	FS.E-G30-40-2-2
FLZ	FS.E	FLZ4000 11 1000-VO	FS.E-B40-56-1-1
FLSE	FE.E	FLSE 3000 2MH000-VG	FE.E-G30-A-4
FLS-S1	FSZ.E	FLS 3000 11 1000-S1-VO	FSZ.E-B30-40-1-1
FLZ-S1	FSZ.E	FLZ 4000 18 2000-S1-VG	FSZ.E-G40-56-2-8
FLSE-S1	FEZ.E	FLSE 3000 2MH000-S1-D-VG	FEZ.E-G30-B-4
FLR	FM.E	FLR 3000 12 1100-VO	FM.E-B30-1-2
FLV	FM.E	FLV 5000 11 1100-VO	FM.E-V50-1-1
FUK	BK.E	FUK 1800 12 2000-VO	BK.E-B18-2-2
FUKE	BK.E	FUKE 1800 2M2000-VG	BK.E-G18-2-ED
FUS	BS.E	FUS 5000 12 2000-VG	BS.E-G50-85-2-2
FUZ	BS.E	FUZ 4000 18 1000-VO	BS.E-B40-70-1-8
FUSE	BE.E	FUSE 3000 2MH000-D-VG	BE.E-G30-B-4
FUR	BM.E	FUR 5000 12 2200-VO	BM.E-B50-2-2
FUV	BM.E	FUV 3000 11 1100-VO	BM.E-V30-1-1
FZR	BML.E	FZR 4000 18 2000-VO	BML.E-B40-2-8
FZV	BML.E	FZV 5000 11 1100-VO	BML.E-V50-1-1
LBK	LKP.E	LBK 1800 12 2000-VG	LKP.E-G18-2-2
LDS	LSQ.E	LDS 3000 18 1000-VO	LSQ.E-B30-OZ-1-8
WIK	TK.E	WIK 1818 12 2200-VO	TK.E-B18-B18-2-2
WIKE	TK.E	WIKE 1818 2M 2200-VG	TK.E-G18-B18-2-ED

Old Nr.	New Nr.	Order key old	Order key new
WIS	TS.E	WIS 3030 12 1100-VO	TS.E-B30-B30-40-1-2
WIZ	TS.E	WIZ 4040 18 2200-VG	TS.E-G40-B40-56-2-8
WISE	TE.E	WISE 5050 2MHH00-VG	E.E-G50-B50-A-4